




Marka:	TRESNAR
Model:	(4661)

Item No.	Part Name	Item No.	Part Name	Item No.	Part Name	Item No.	Part Name
1	Front cover	31	Sping washer	61	Clip ring	91	Cable protecting sleeve
2	Clip ring	32	Screw	62	Clip ring	92	Vdeplug
3	Steel ball rack	33	Gear box	63	Top hammer spring	93	Right handle
4	Steel ball rack spring	34	Screw	64	Key	94	Screw m
5	Front placket	35	Overlay	65	First gear	95	Flat washer
6	Oil seal	36	Oil cover	66	Support sleeve	96	Knob
7	Washer	37	O ring	67	Top hammer	97	Button spring
8	Clip ring	38	Eccentric shaft	68	Needle bearing	98	Button
9	Bearing	39	Sping washer	69	Middle cover wash	99	Knob shaft
10	Steel ball	40	Flat washer	70	Rubber column	100	Screw
11	Rotary sleeve	41	Damping rubber sleeve	71	Steel ball	101	Sping washer
12	O ring	42	Damping spring	72	Middle shaf	102	Flat washer
13	O ring	43	Damping plate	73	Button	103	Left gear box
14	Impact hammer	44	Damping screw	74	Bearing	104	Right gear box
15	Steel ball	45	Screw	75	Rotor	S-101	Side handle hoop
16	Cylinder	46	Small gear	76	Bearing	S-102	Clamping screw
17	Key	47	Ring	77	Distance sleeve of axletree	S-103	Hexagon bolt
18	Rubber ring	48	Bearing	78	Screw	S-104	Nut m6
18	Spring	49	Bearing washer	79	Anti-wind ring	S-105	Auxiliary handle support
20	Distance set	50	Second gear	80	Stator	S-106	Auxiliary handle
21	O ring	51	Fix block	81	Housing	S-107	Depth gauge
22	Big gear	52	Clip ring	82	Brusher houlder shelf		
23	Clip ring	53	Steel ball	83	Carbon brush copper		
24	Cylinder hammer	54	Active plate	84	Carbon brush		
25	O ring18*3.05	55	Inner spring	85	Back cover		
26	Piston	56	Outer spring	86	Left handle		
27	Piston wash	57	Spring plate	87	Switch		
28	Piston pole	58	Clip ring	88	Capacitor		
29	Oil bearing	59	Bearing	89	Speed controller		
30	Oil bearing	60	Bearing	90	Cable fixing plate		

Marka:	TRESNAR
Model:	(4661)