





1

Marka:	TRESNAR
Model:	4542

Item No. Part Name

1	Screw
2	Flat washer
3	Sanding pad
4	Output shaft
5	Flat key
6	Oil seal
7	Collar
8	Ball bearing
9	Screw
10	Big bearing cover
10A	Paper washer
11	End gear
12	Circlip
13	Ball bearing
15	Small bearing cover
16	Ball bearing
16A	Circlip
17	Main driving shaft
17A	Washer
18	Semi-circular key
19	Tapered gear
20	Circlip
21	Gear box
22	Middle cover
22A	Spring of rotor
22B	Wool cap
23	Rotor
23A	Anti-dust ring
24	Ball bearing
25	Anti-wind ring
26	Screw
26A	Circular button

Item No. Part Name

27	Stator
27A	Sleeve
28	Housing
28A	Flat washer
28B	Flexible washer
29	Screw
30	Brush holder
31	Carbon brush
32	Screw
33	Coil spring
34	Cover
34A	Screw
35	Screw
36	Pressing block on motor housing
37	Horn damping
38	Big rubber sleeve
39	Screw pin
40	Flexible sleeve
41	Brush segment
42	Pressing plate for cable sleeve
43	Sanding pad cover
44	Compressed spring
45	Flat washer
46	Waved sleeve
47	End block for dust collection cover
48	Dust collection cover
49	Tightening ring
50	Hose
51	Small cable sleeve
52	Small rubber cover
53	Right handle stand
54	Φ28 connector
55	Plastic soft pipe
56	Ellipticle connector
57	Left handle stand
58	Inductance
59	Left main handle

Item No. Part Name

60	Capacitance
61	Electronic speed control plate
62	Switch
63	Cable sleeve
64	Aluminum pipe
65	Clinch bolt
66	Front hinge sleeve
67	Sealed ring
68	Pin
69	Back hinge sleeve
70	Pin
71	Pin
72	Back cable pressing plate
73	Lock wrench
74	Brace
75	Sleeve
76	Spring
77	Front cable pressing plate
78	Black aluminum pipe with double access
79	Cable sleeve
80	Cable
81	Right main handle
82	Aluminum pipe insert
83	Back screw nut
84	Left sub-handle
85	Aluminum pipe with single access
86	Right sub-handle
87	Adjustable ring
88	Protection connection adapter

Marka:	TRESNAR
Model:	4542