




tresnar

Marka:	Tresnar
Model:	(6690)

Item No.	Part Name
1	Screw
2	Chuck
3	Output spindle
4	Steel ball
5	Ball bearing 6000-2Z
6	Snap ring
7	Driven gear
8	Spring
9	Wearing washer
10	Needle bearing
11	Central support bracket
12	Steel plate
13	Function shift knob
14	Metal plate
15	Ball bearing 608-2Z
16	Rotor
17	Ball bearing
18	Bearing bushings
19	Stator

Item No.	Part Name
20	Stator locator pin
21	Housing
22	Left label
23	Plastic block
24	Brush housing
25	Carbon brush
26	Forwarder/ reverse knob
27	Switch
28	Inductor
29	Cable protector
30	Cable
31	Capacitor
32	Upper housing
33	Self-tapping screw
34	Right label
35	Auxiliary handle
36	Depth stop
37	Chuck key

Marka:	Tresnar
Model:	(6690)